




1. Install driver:



Open files , find the driver as followings, if computer

system with 64bits, install  CP210xVCPInstaller\_x64 ;

If computer system with 32 bits , install  CP210xVCPInstaller\_x86



2. Install software:

